

# MIST-IFY Nano ➤ TROUBLESHOOTING GUIDE

- Read instructions prior to use. Please note that there is a protective film over the gloss black areas that surround the nozzle at the front of the unit and there is a second area which has a protective film at the rear of the unit again covering the gloss black area which surrounds the on/off button & mode button. To ensure that this does not hinder the unit's operation, this should be removed prior to first use as it could affect the operation of both the nozzle and the button.
- To charge, plug the C type end of the charging lead into unit, plug the other end of the USB cable into the USB outlet or into a **5V 2 amp 3 Pin Plug** (Not Supplied), then plug it into an electrical socket. The **MIST-IFY** Nano is to be used with plugs that hold a 2 amp rating. Many phone plugs carry a 1 amp rating, so a **2 amp plug** will be required.
- It can also be charged via some electronic devices such as laptops and PCs, via USB.
- Charging time is approx. 2-3 hours. When charging, the **blue** indicator lights flash. When fully charged all four blue lights will be lit.
- To operate, fill the bottle with our **MIST-IFY Instant Sanitiser**. Switch the unit on with the on/off switch. Press and hold the button marked 'M' for over 2 seconds until the unit defaults to the Low **MIST** setting. For greater volume, press and hold the 'M' button for over 2 seconds on each occasion to toggle through Low, Middle & High **MIST** volumes.
- If you wish to see the **MIST** more clearly press the 'M' button twice in quick succession this will turn on the **blue MIST** monitor light. To turn it off, repeat this process.

Image 1



Image 2



- This machine is to be used with **MIST-IFY Instant Sanitiser** only, which it has been designed to work with.
- On first usage it may take longer before **MIST** can be seen exiting the **Nano**.
- If a blockage is suspected, switch on the **Nano** ensuring there is **MIST-IFY Instant Sanitiser** in the container and gently squeeze the container. This will force the liquid through the machine, clearing any blockages. **See Image 3**
- If a blockage in the filter is suspected switch on the machine & place your finger over the **MIST** exit nozzle. You should then see bubbles appearing from the filter which is in the clear container. If no bubbles appear remove the container. Then remove the filter (pulls off) re-fit the container and retry the procedure of unblocking the nozzle. If the unit now works, a replacement filter can be supplied from **Coler Medical PPE**. **See Image 4**
- If left for long periods, empty the container of any remaining **MIST-IFY Instant Sanitiser** & replace with clean lukewarm water. Then flush this through the Nano by using the unit for 5 minutes at it highest **MIST** volume setting.
- Keep the charging port dry.

Image 3



Image 4

